



Guide bushing offset is determined by subtracting the bit diameter from the bushing O.D. Then dividing by 2.  $(1/2'' \text{ collar} - 1/4'' \text{ bit} / 2 = 1/8'' \text{ offset}.$